

IWAKI Magnetic Drive Pump

MX Series (MX-250/-505)

Instruction Manual (Asia)

 Read this manual before use of product

Thank you for selecting an Iwaki MX Series Magnetic Drive Pump. This instruction manual deals with "*Safety instructions*", "*Outline*", "*Installation*", "*Operation*" and "*Maintenance*" sections. Please read through this manual carefully to ensure the optimum performance, safety and service of your pump.

Contents

Important instructions	1
Safety instructions	2
<i>Outline</i>	
1. Unpacking & Inspection	7
2. Product outline	7
3. Model code	8
4. Specification	9
5. Dimension	10
6. Part names	11
7. Overview	15
<i>Installation</i>	
1. Before installation	17
2. Installation/Pipework/Wiring	19
<i>Operation</i>	
1. Operational precautions	26
2. Before operation	27
3. Operation	27
<i>Maintenance</i>	
1. Troubleshooting	30
2. Maintenance & Inspection	31
3. Spare & Wear parts	34
4. Disassembly & Assembly	35



This instruction manual should be kept on hand by the end user for quick reference.

Contact us or your nearest dealer if you have any questions.

Important instructions

For the Safe and Correct Handling of the Pump

- "Safety Instruction" section deals with important details about handling of the product. Before use, read this section carefully for the prevention of personal injury or property damage.
- Observe the instructions accompanied with "WARNING" or "CAUTION" in this manual. These instructions are very important for protecting users from dangerous situations.
- The symbols on this instruction manual have the following meanings:

 WARNING	Nonobservance or misapplication of "Warning" sections could lead to a serious accident which may result in death.
 CAUTION	Nonobservance or misapplication of "Caution" sections could lead to personal injury or property damage.

Types of Symbols



Indicates that "Warning" or "Caution" must be exercised. Inside this triangle, a concrete and practical image provided as a warning or caution message is depicted.



Indicates a prohibited action or procedure. Inside or near this circle, a concrete and practical image of the activity to be avoided is depicted.



Indicates an important action or procedure which must be performed or carried out without fail. Failure to follow the instructions herein can lead to malfunction or damage to the pump.

Export Restrictions

Technical information contained in this instruction manual might be treated as controlled technology in your countries, due to agreements in international regime for export control. Please be reminded that export license/permission could be required when this manual is provided, due to export control regulations of your country.

Safety instructions

WARNING

- **Turn off power before service**

Risk of personal injury. Before performing any service, turn off power to stop the pump and related devices and display a warning sign near the power switch to prevent others from restoring power during service.



Requirement

- **Stop operation**

If you notice any abnormal or dangerous conditions, suspend operation immediately and inspect/solve problems.



Requirement

- **Do not use the pump in any condition other than its intended purpose**

The use of the pump in any conditions other than those clearly specified may result in failure or injury. Use this product in specified conditions only.



Prohibited

- **Do not modify the pump**

Alterations to the pump carry a high degree of risk. It is not the manufacturer's responsibility for any failure or injury resulting from alterations to the pump.



Do not rework
or alter

- **Wear protective clothing**

Always wear protective clothing such as an eye protection, chemical resistant gloves, a mask and a face shield during disassembly, assembly or maintenance work. The specific solution will dictate the degree of protection. Refer to SDS precautions from the solution supplier.



Wear
protection

- **Use strong ropes (chains) for lifting up the pump**

Keep away from the pump while it is lifted up for installation. Serious injury may result if lifting ropes (chains) break. Observe the working load limit of the ropes (chains).



Requirement

- **Use the eye bolts (if provided)**

Use the eye bolts when lifting the pump. Otherwise the pump may fall and cause serious injury.



Requirement

Safety instructions

WARNING

- **Do not lift the pump by holding any plastic parts (pump unit, flange, or base)**

If a plastic part breaks, the pump may fall, resulting in serious injury.



Prohibited

- **Daily inspection and maintenance**

Risk of personal injury, fire, or even explosion. Daily inspection and maintenance are required for the prevention of chemical spray or leakage when handling:

- Explosive or flammable liquid,
- Corrosive or stimulus toxic liquid, or
- Harmful liquid.



Prohibited

- **Do not damage the power cable**

Do not pull, knot, or crush the power cable. Damage to the power cable could lead to a fire or electrical shock if cut or broken.



Prohibited

- **Do not operate the pump in a flammable atmosphere**

Do not place explosive or flammable material near the pump.



Fire ban

- **Do not catch the finger**

Magnetic force of the pump is powerful. When taking apart or putting together the pump, take measures not to catch the finger in the bracket.



Requirement

- **Access limitation**

The magnet drive pump has a pair of strong magnets (the magnet capsule unit and drive magnet). The strong magnet field could adversely affect the persons who are assisted by electronic devices such as the pacemaker.



Requirement

Safety instructions

CAUTION

• Qualified personnel only

The pump should be handled or operated by qualified personnel with a full understanding of the pump. Any person not familiar with the product should not take part in the operation or management of the pump.



Requirement

• Use specified power only

Do not apply power other than that specified on the nameplate. Otherwise, failure or fire may result. Ensure the pump is properly grounded.



Requirement

• Do not run pump dry

Do not run pump dry (operation without priming water or with a suction valve closed). Internal parts are excessively worn by friction heat and fatal pump damage results.



Prohibited

• Ventilation

Fumes or vapours can be hazardous with certain solutions. Ensure proper ventilation at the operation site.



Requirement

• Do not install/store the pump:

- In a flammable/explosive/corrosive atmosphere.
- In a dusty/humid environment.
- Where ambient temperature can exceed 0-40°C.
- Under mechanical vibrations.
- In direct sunlight or wind & rain.



Prohibited

• Spill precautions

Ensure protection and containment of solution in the event of plumbing or pump damage (secondary containment). Do not drain the liquid onto the floor.



Requirement

• Do not stand on the pump

Injury or damage may result when the pump turns over.



Prohibited

• Do not touch the pump or pipe with bare hands

Risk of burns. The surface temperature of the pump or piping becomes very high during and immediately after operation, depending on the liquid temperature.



Caution

Safety instructions

CAUTION

- **Grounding**

Risk of electric shock! Always properly ground the pump. Conform to local electric codes.



- **Install a GFCI (earth leakage breaker)**

An electrical failure of the pump may adversely affect other devices on the same line. Purchase and install an earth leakage breaker separately.



- **Before starting the pump**

Ensure no one is around the pump before connecting the power. The pump does not have an ON-OFF switch and starts automatically when the power cable is plugged in.



- **Remove foreign matter**

If foreign matter enters the pump, turn off the power and clean the pump. Otherwise, the pump may be damaged.



- **Static electricity**

When low electric conductivity liquids such as ultra-pure water and fluor inactive liquid (e.g. Fluorinert™) are handled, static electricity may be generated in the pump and may cause static discharge. Take countermeasures to remove static electricity.



- **Preventative maintenance**

Follow the instructions in the manual for replacing wear parts. Do not disassemble the pump beyond the instructions provided.



- **Do not use a damaged pump**

Use of a damaged pump could lead to an electric shock or death.



- **Disposal of a used pump**

Remove the liquid and flush it out before the pump is disconnected from piping. Dispose of any used or damaged pump and removed the liquid in accordance with local rules and regulations. If necessary, consult a licensed industrial waste disposal company.




Outline

<i>1. Unpacking & Inspection</i>	<i>7</i>
<i>2. Product outline.....</i>	<i>7</i>
<i>3. Model code</i>	<i>8</i>
<i>4. Specification</i>	<i>9</i>
<i>5. Dimension.....</i>	<i>10</i>
<i>6. Part names</i>	<i>11</i>
<i>7. Overview</i>	<i>15</i>

Outline

1. Unpacking & Inspection




On unpacking the product, check the following points. If you find any problems, contact your nearest distributor.

1. Check the information on nameplate (model code, flow rate, head and voltage) to see if the product is delivered as per order.
2. Check for transit damage, deformation, and loose bolts.

2. Product outline

The MX is a magnetic drive centrifugal pump capable of handling various liquid.



■ Principle of operation

The magnetic force between drive and driven magnets rotates the impeller in the pump chamber, where a liquid is transferred from the inlet to outlet.

Outline

3. Model code

MX - 400 C V 6 C - 2 S
 a b c d e f g

a. Pump I.D. and motor output

Code	Pump I.D. (Inlet × Outlet)	Motor output
250	25A × 25A	0.37kW
251		0.75kW
400	40A × 40A	0.37kW
401		0.75kW
402/402H	50A × 40A	1.5kW
403/403H		2.2kW
505	65A × 50A	3.7kW

*The motor is 2-pole, 3-phase.

b. Sliding parts

C: Carbon bearing × Alumina ceramic spindle

R: Filled PTFE bearing × Alumina ceramic spindle

A: Alumina ceramic bearing × Alumina ceramic spindle (available for MX-250/-251/-400/-401)

c. O ring materials

V: FKM

E: EPDM

A: Aflas®

d. Impellers

3, 5, 7 : 50Hz

4, 6 : 60Hz

*The code "7" is used with an IE2 high efficiency motor. Applicable models are the MX-250/-251/-400/-401.

*The code "3" and "4" are used with an IE3 premium efficiency motor. An applicable model is the MX-401.

e. Motors

No code: Totally-enclosed-fan-cooled motor for indoor use

C: Totally-enclosed-fan-cooled motor for outdoor use

A: Increased safety motor

f. Motor power voltage

MX-250/-251/-400/-401 (3-phase standard motor)	MX-402(H)/-403(H) (3-phase IEC motor)	MX-505 (3-phase IEC motor)
2: 200/220V	2: 200/220V	2: 200/220V
4: 380/400/415V (50Hz) or 440V(60Hz)	6: 380V	6: 380V
9: 460V	7: 400/440V	7: 400/440V
	8: 415V	9: 460V
	9: 460V	

g. Special version

S : Special version

Outline

4. Specification

Model	Inlet × Outlet	S.G. limit	Motor output
MX-250	25×25	1.0	0.37kW
MX-251	25×25	1.0	0.75kW
MX-400	40×40	1.2	0.37kW
MX-401	40×40	1.2	0.75kW
MX-402	50×40	1.2	1.5kW
MX-402H	50×40	1.0	1.5kW
MX-403	50×40	1.2	2.2kW
MX-403H	50×40	1.0	2.2kW
MX-505	65×50	1.2	3.7kW


■ Pump weight

Model	MX-250/-400	MX-251/-401	MX-402/-402H	MX-403/-403H	MX-505
MX	13.5kg	18.5kg	30.5kg	33kg	53.5kg
MX (IE3)	-	22kg	38kg	43kg	64kg


Outline

5. Dimension

MX-250/-251/-400/-401/-402(H)/-403(H)



MX-505




Model	W	H	L	a	b	c	d	e	f	g	k
MX-250	160	247.5	411	130	65	130	115	140	90	163	12
MX-251	160	247.5	444	130	65	130	115	140	90	171	12
MX-251 (IE3)	160	247.5	446	130	65	130	115	140	90	171	12
MX-400	140	219	411	110	54	98	95	130	87	150	12
MX-401	160	249	457	130	72	130	115	140	103	184	12
MX-401 (IE3)	160	249	459	130	72	130	115	140	103	184	12
MX-402(H)/-403(H)	260	274	516	208	80	200	120	160	89	157	14×36
MX-402(H)/-403(H)(IE3)	260	274	514/543	208	80	200	120	160	89	157	14×36
MX-505	180	330	601	140	96	220	150	180	95	175	14

NOTE: Actual dimensions may differ from the above information depending on model identification codes.

Outline

6. Part names

MX-250/-251/-401




No.	Names	Q'ty	MX-250		MX-251		MX-401	
			Materials	Remarks	Materials	Remarks	Materials	Remarks
1	Front casing	1	GFRPP		GFRPP		GFRPP	
2	Rear casing	1	GFRPP		GFRPP		GFRPP	
3	Impeller	1	GFRPP		GFRPP		GFRPP	
5	Drive magnet unit	1	Ferrite mag. +aluminum alloy		Ferrite mag. +FCD450		Ferrite mag. +FCD450	
8	Magnet capsule	1	Ferrite mag. +PP		Ferrite mag. +PP		Ferrite mag. +PP	
9	Hex socket set screw	2	Steel	M8 × 10	Steel	M8 × 10	Steel	M8 × 10
11	Hex soch head bolt	6	Stainless steel	M8 × 35, with PW, SW	Stainless steel	M8 × 35, with PW, SW	Stainless steel	M8 × 40, with PW, SW
12	Hex soch head bolt	2	Stainless steel	M8 × 50, with PW, SW	Stainless steel	M8 × 50, with PW, SW	Stainless steel	M8 × 50, with PW, SW
13	Flange	2	GFRPP		GFRPP		GFRPP	
15	Motor	1						
16	Base	1	GFRPP		GFRPP		GFRPP	
17	Adapter	1	FC200		FC200		FC200	

No.	Names	Q'ty	Materials			MX-250/-251	MX-401
			CV/CE	RV/RE	AV/AE	Remarks	Remarks
18	Liner ring	1	Alumina ceramic 99.5%				
19	Rear thrust	1	CFRPPS				
20	Spindle	1	Alumina ceramic 99.5%				
21	Bearing	1	High density carbon	Filled PTFE	Alumina ceramic		
22	Mouth ring	1	Filled PTFE				
23	O ring	1	V: FKM E: EPDM			JIS B 2401 G165	JIS B 2401 G165
24	O ring	2	V: FKM E: EPDM			JIS B 2401 G25	AS568-129
27	Hex soch head bolt	4	Steel			M8 × 20, with PW, SW	M8 × 20, with PW, SW

Outline


MX-400



No.	Names	Q'ty	Materials	Remarks	No.	Names	Q'ty	Materials			Remarks
								CV/CE	RV/RE	AV/AE	
1	Front casing	1	GFRPP		18	Liner ring	1	Alumina ceramic 99.5%			
2	Rear casing	1	GFRPP		19	Rear thrust	1	CFRPPS			
3	Impeller	1	GFRPP		20	Spindle	1	Alumina ceramic 99.5%			
5	Drive magnet unit	1	Ferrite magnet +aluminum alloy		21	Bearing	1	Carbon	Filled PTFE	Alumina ceramic 99%	
8	Magnet capsule	1	Ferrite magnet +PP								22
9	Hex socket set screw	2	Steel	M8 × 10	23	O ring	1	V: FKM E: EPDM			JIS B 2401 G135
11	Hex soch head bolt	4	Stainless steel	M8 × 30, with PW, SW	24	O ring	2	V: FKM E: EPDM			AS568-129
12	Hex soch head bolt	2	Stainless steel	M8 × 40, with PW, SW	27	Hex soch head bolt	4	Steel			M8 × 20, with PW, SW
13	Flange	2	GFRPP								
15	Motor	1									
16	Base	1	GFRPP								
17	Adapter	1	FC 200								

Outline

MX-402(H)/-403(H)




No.	Names	Q'ty	Materials	Remarks	No.	Names	Q'ty	Materials		Remarks
								CV/CE	RV/RE	
1	Front casing	1	GFRPP		18	Liner ring	1	Alumina ceramic 96%		
2	Rear casing	1	GFRPP		19	Rear thrust	1	CFRPEEK		
3	Impeller	1	GFRPP		20	Spindle	1	Alumina ceramic 99.5%		
4	Drive magnet unit	1	Rear earth magnet +FCD450		21	Bearing	1	Carbon	Filled PTFE	
8	Magnet capsule	1	Rear earth magnet +PP		22	Mouth ring	1	Filled PTFE		
					23	O ring	1	V: FKM E: EPDM		JIS B 2401 G195
9	Hex socket set screw	2	Steel	M8 × 10	24	O ring	1	V: FKM E: EPDM		AS568-136
10	Hex head bolt	4	Stainless steel	M10 × 30*, with SW	25	O ring	1	V: FKM E: EPDM		AS568-129
11	Hex soch head bolt	7	Stainless steel	M10 × 45, with PW, SW	26	Hex soch head bolt	4	Steel		M8 × 20, with PW, SW
12	Hex soch head bolt	1	Stainless steel	M10 × 60, with PW, SW	27	Lock pin	2	GFRPPS		
13	Flange in	1	GFRPP							
14	Flange out	1	GFRPP							
15	Motor	1								
16	Base	1	GFRPP							
17	Adapter	1	FC200							

*IE3 motor: M10×25

Outline


MX-505



No.	Names	Q'ty	Materials	Remarks	No.	Names	Q'ty	Materials		Remarks
								CV/CE	RV/RE	
1	Front casing	1	GFRPP		18	Liner ring	1	Alumina ceramic 99.5%		
2	Rear casing	1	GFRPP		19	Rear thrust	1	CFRPEEK		
3	Impeller	1	GFRPP		20	Spindle	1	Alumina ceramic 99.5%		
4	Drive magnet unit	1	Rear earth magnet +FCD450		21	Bearing	1	Carbon	Filled PTFE	
8	Magnet capsule	1	Rear earth magnet +PP		22	Mouth ring	1	Filled PTFE		
					23	O ring	1	V: FKM E: EPDM	JIS B 2401 G230	
9	Hex socket set screw	2	Steel	M8 × 10	24	O ring	1	V: FKM E: EPDM	JIS B 2401 G70	
10	Hex head bolt	4	Stainless steel	M12 × 35, with SW	25	O ring	1	V: FKM E: EPDM	JIS B 2401 G55	
11	Hex soch head bolt	6	Stainless steel	M10 × 45, with PW, SW	27	Lock pin	2	GFRPPS		
12	Hex soch head bolt	2	Stainless steel	M10 × 75, with PW, SW						
13.1	Flange in inner	1	GFRPP							
13.2	Flange in outer	1	GFRPP							
14.1	Flange out inner	1	GFRPP							
14.2	Flange out outer	1	GFRPP							
15	Motor	1								
17	Adapter	1	FC200							

Outline

7. Overview



CAUTION

Wet a cloth with tap water and wring it out for cleaning the pump. Use a neutral detergent for greasy dirt and then rub with a dry cloth. Do not wipe nameplates, labels or pump body with any solvent.

Installation

<i>1. Before installation</i>	<i>17</i>
<i>2. Installation/Pipework/Wiring</i>	<i>19</i>

Installation

CAUTION

- **Do not run pump dry**

Do not run pump dry (operation without priming water or with a suction valve closed). Otherwise, internal parts are excessively worn by friction heat and fatal pump damage results.

*If the pump runs dry by mistake, turn off power and leave it for more than one hour to cool it down. Quick cooling can give rise to cracks on parts.

*An Iwaki DRN dry run protector is recommended for the prevention of dry running.



Prohibited

- **Do not operate the pump in a flammable atmosphere**

Do not place explosive or flammable material near the pump.



Prohibited

- **Do not modify the pump**

Alterations to the pump carry a high degree of risk. It is not the manufacturer's responsibility for any failure or injury resulting from alterations to the pump.



Prohibited

1. Before installation

Always observe the following points.

- **Precautions for starting/stopping the pump
(In case the pump is in flooded suction system.)**

Follow the procedures below when starting/stopping the pump for the prevention of water hammer.

Take extra care when a discharge line is long.

When starting the pump

First, prime the pump. Then turn on power to start operation with a discharge valve fully closed.

And then gradually open the valve and adjust a flow rate to a specified point.

When stopping the pump

Gradually close a discharge valve. Turn off power and stop the pump after the valve is fully closed.

NOTE: Do not close a discharge valve sharply. Otherwise an excessive pressure may damage the pump, when using a solenoid valve, set it to close slowly.

- **Do not install or store the pump:**

- Where ambient temperature can exceed 40 °C or falls below 0 °C.
- Where ambient humidity can exceed 85%RH or falls below 35%RH.
- In a corrosive/explosive environment.
- In direct sunlight or wind & rain (except outdoor-use type).
- Under mechanical vibration.

Installation

■ Always prime the pump

The MX is not a self-priming pump. Prime the pump every time the pump is operated. Do not run pump dry (operation without liquid.), or internal parts seizing or excessive wear results.

■ Maximum operating pressure

Do not allow a discharge pressure to exceed the limits below.

Model	MX-250	MX-251	MX-400	MX-401	MX-402 /-403	MX-402(H) /-403(H)	MX-505
Pressrue limits (MPa)	0.25	0.33	0.22	0.28	0.43	0.5	0.33

■ Liquid conditions

Slurry

The MX series can not send slurry except the pumps with a SiC bearing and a SiC spindle (sliding parts code: A).

The A type can handle slurry up to 5% (concentration), 50µm (particle size) and 80Hs (hardness).

Contact us for details.

Performance change

Shaft power, discharge capacity and pump head vary depending on specific gravity and viscosity. The pump is designed for a specified liquid. If you made a change to the liquid property, contact us.

SiC bearing

A SiC bearing can be worn greater than other materials depending on liquid property including liquid viscosity. Contact us for detail.

Temperature change

Viscosity, vapour pressure and corrosive nature vary with liquid temperature. Always take account of temperature change.

▶ Allowable liquid temperatrue: 0-80°C (clean water)
▶ Allowable ambient temperature: 0-40°C
▶ Allowable ambient humidity: 35-85%RH

NOTE: Contact us for the allowable liquid temperature range at each liquid type.

■ Intermittent operation

Frequent ON-OFF operation damages the pump in a short time. Do not make ON-OFF operation more than six times per hour.

■ Disconnection of magnet coupling

Stop the pump immediately when the magnet coupling is disconnected. Otherwise magnetic force reduces.

■ Ascending area of a spike curve (in a performance curve)

When a specified point falls on an ascending area of a spike curve (generally, a flow is small in this area.

See the standard performance curves), check and observe the following points.

- There should be no possibility of trapping air in a supply tank or a discharge line.
- A discharge valve should be installed near the pump outlet to adjust a flow rate.

Installation

2. Installation/ Pipework/ Wiring

If you notice any abnormal or dangerous conditions, suspend operation immediately and inspect/solve problems.

WARNING

- **Turn off power before work**

Be sure to turn off power to stop the pump and related devices before work. Make sure no one turns on power by mistake while working on the pump, otherwise it may result in a serious accident. If your working area is noisy or dark, let other people know about the situation by displaying a notice such as "POWER OFF (Maintenance)" near a power switch.



Turning off power

- **Do not lift the pump by holding any plastic parts (pump unit, flange or base)**

If a plastic part breaks, the pump may fall, resulting in serious injury.



- **Electrical wiring**

Electrical work should be performed by a qualified electrician. Otherwise, personal injury or property damage may result.



Caution

■ **Carrying in and out**


When carrying in and out the pump, observe the following points.

- Do not lift the pump by holding plastic parts such as a pump unit, a flange or a base.
- Mount the pump horizontally on a pump base.

Installation

■ Installation

Arrange pump and pipework based on the following piping layout for a long period of operation.



1. Discharge pipe
(Support pipework to keep the pump free of piping weigh.)
2. Gate valve
3. Check valve
4. Pressure gauge
5. Motor
6. Pump
7. Air vent/ priming line
9. Drain ditch
10. Vacuum gauge
11. Suction pipe (Pipe diameter: D)
(Horizontal sections should be shortest and laid on a rising gradient of 1/100 toward the pump)
12. Pipe support
13. Suction pipe (Pipe diameter: D)
14. 2D or 500mm or more
15. Expansion joint
16. Flushing line (Discharge side)
17. Flushing line (Suction side)

Installation location

- Install the pump as close to a supply tank. Keep a liquid level in the tank higher than the pump at any time (flooded suction application).
- In case the pump is installed above a liquid level (suction lift application), lay on a priming line and mount a foot valve to the bottom of a suction line.

NOTE: The maximum suction lift varies with liquid characteristics, specific gravity, liquid temperature and suction line length. Contact us for detail.

Outdoor use motors (Indoor use motors can not be installed out of doors)

Outdoor use motors can also be used in doors. Protect the motor and electrical power distribution equipment from possible damage due to an accidental outflow or act of providence.

Installation space


- Select a level location, free from vibration, that won't hold liquid.
- Allow sufficient space around the pump for easy access and maintenance.

⚠ CAUTION

Fix the pump firmly. Support piping so as not to directory weigh on the pump.

Installation

■ Foundation work



- Installation area should be larger than the footprint of the pump. Or a plastic base may break due to a concentrated load.
- If piping vibrates sympathetically with the pump in operation, provide an expansion joint between the pump and the piping to reduce vibration.


■ Tightening torque between the pump and pipework

Connect the pump to pipework via inlet and outlet flanges according to the tightening torque below. The table is based on use of metal pipe flanges with rubber gaskets. Tighten bolts diagonally at even torque.

Model	Bolt size	Tightening torque
MX-250/-251/-400/-401/-402/-403/-505	M16	20N•m

■ Piping load and momentum

Try not to apply a heavy load to the inlet and outlet flanges. Permissible piping weight and moment to the pump are as below.



Installation

Permissible stress to outlet flange

	Pipe dia. (mm)	
	25	40, 50
	Load	
Load direction	kN	
Fx	0.10	0.15
Fy: compression	0.15	0.20
Fy: tension	0.10	0.10
Fz	0.10	0.15

Permissible stress to inlet flange

	Pipe dia. (mm)	
	25	40, 50, 65
	Load	
Load direction	kN	
Fx	0.10	0.10
Fy	0.10	0.15
Fz	0.10	0.15

Permissible moment to outlet flange

	Pipe dia. (mm)	
	25	40, 50
	Moment	
Load direction	kN·m	
Mx	0.02	0.05
My	0.05	0.10
Mz	0.05	0.10

Permissible moment to inlet flange

	Pipe dia. (mm)	
	25	40, 50, 65
	Moment	
Load direction	kN·m	
Mx	0.05	0.10
My	0.02	0.05
Mz	0.05	0.10

■ Suction line

1. Always build up a flooded suction system. Have a suction line shortest with the minimum number of bends. Support piping by pipe supports so that the pump is not subject to piping weight or thermal stress.
2. Make sure joints on a suction line are secure and air doesn't come in. If air is entrained into a suction line, liquid may not be pumped or the pump may break at its worst.
3. When the inner pressure of a supply tank is negative, or a suction lift or a suction line is long, apply the following formula.









$$NPSHa > NPSHr + 0.5m$$
 (See the standard performance curve for NPSHr.)
4. If a bent pipe is installed in a suction line, lay a straight line (length: 500mm or longer, or 8 times longer than the inlet I.D. of the pump) between a pump inlet and the bent pipe. Also, have the curvature radius of the bent pipe largest.
5. Do not allow any arched line where air may be trapped. A suction line should be laid on a rising gradient of 1/100 toward the pump.
6. If the inlet I.D. of the pump is different from that of a suction pipe, use an eccentric reducer pipe. Upper side should always be level. Air may be trapped if it is mounted upside down.

Installation

7. In flooded suction, install a gate valve on a suction line for easier overhaul & inspection. Keep this valve open at any time during operation.
8. Install a flushing line for cleaning the pump after handling a harmful liquid.
9. A suction pipe I.D. should be equal to or larger than a pump inlet I.D.

Suction lift application

10. One end of a suction line should always be at least 500 mm lower than a liquid level in a supply tank for the prevention of air ingress.
11. Provide a screen in a supply tank for the prevention of foreign matter interfusion (Clean the screen periodically.). The distance between the end of a suction line and the bottom of a suction tank should be 1.5 times wider than a suction line I.D.
12. Be sure to install a foot valve at one end of a suction line.

Good conditions	Unacceptable conditions
	 <p style="text-align: right;">Trapped air</p>
	 <p style="text-align: right;">Trapped air</p>
	 <p style="text-align: right;">Trapped air</p>
	

Installation

■ Discharge line

1. Support discharge piping so as not to directly weigh on the pump.
2. Lay a priming line when the pump is not under a flooded suction system.
3. Pipe resistance rises too high to obtain an intended flow if a discharge pipe I.D. is too long. Always take account of the increment of pipe resistance.
4. Install a check valve in the following cases.
When selecting a check valve, check its maximum operating pressure to make sure it tolerates a possible pressure rise due to water hammer or backflow.
 - A discharge line is too long.
 - Actual discharge head (static discharge head plus discharge pipe resistance) is more than 15m.
 - The end of a discharge line is 9m higher than a liquid level in a supply tank.
 - Several pumps are running in parallel.
5. Install a gate valve on a discharge line to adjust a flow rate and to protect a motor from overload. If you are to install a check valve as necessary, it should be mounted in between the pump and the gate valve.
6. Install a pressure gauge on a discharge line.
7. Install an air vent line when a discharge line is laid long in a horizontal direction.
8. Drain
Install a drain valve if there is the risk of liquid freezing in the discharge line.

■ Wiring

Electrical wiring and any work on power source must be performed by qualified persons only. It is not the manufacturer's responsibility for any injury and damage due to noncompliance with this notice. Contact us as necessary.

1. Install an electromagnetic switch according to motor specifications (voltage, capacity, etc.).
2. Electromagnetic switches and push buttons should be installed away from the pump.
3. If the pump is used out of doors, protect switches from rainwater.

Operation

<i>1. Operational precautions.....</i>	<i>26</i>
<i>2. Before operation</i>	<i>27</i>
<i>3. Operation.....</i>	<i>27</i>

Operation

1. Operational precautions

CAUTION

- Never run pump dry or shut off a suction valve during operation. Otherwise the pump fails in a short period.
- Check the rotational direction of the pump. Clockwise seen from the motor end is a correct direction. Operation in a reverse direction may cause pump damage.
- Stop the pump immediately when it is running under cavitation. Do not continue to run the pump when air is entrained from a suction line.
- Stop the pump immediately if the magnet coupling is disconnected. Magnetic force reduces if the pump keeps on running for more than one minute in this condition.
- Keep liquid temperature change within 80°C at any time during operation or stop.
- Start the pump with a discharge valve fully closed in order to avoid water hammer.
- Closed-discharge operation should be within one minute. If the pump runs with a discharge valve closed for a long time, the liquid temperature inside the pump rises and damages the pump.
- If power is interrupted while the pump is running, switch off the pump immediately and close a discharge valve.
- Take extra care for a discharge pressure not to exceed the pump limit. See page 18, "Maximum operating pressure".
- The surface temperature of the pump or pipe rises high along with liquid temperature in or right after operation. Take preventive measures.

Model	Liquid temperature	Surface temperature (at ambient 40°C)
MX-250/-251/-400/-401/-402(H)/-403(H)/505	80°C	80°C

- Noise level

Model	MX-250/-400	MX-251/-401	MX-402(H)/-403(H)	MX-505
Noise level	70dB	75dB	80dB	85dB

In case the pump noise affects human health or communication to secure a safety, provide a noise reduction cover. Be careful not to reduce cooling effect by a motor fan.



Operation

2. Before operation

Take the next steps to start the pump at the first operation or after a long period of storage.

1. Clean the inside of piping and a supply tank.
2. Retighten flange fixing bolts and base fixing bolts.
3. Prime the pump and shut off a discharge valve. Check an air vent line and a flushing line are closed.
4. Run the motor for a moment (within a second) in order to check if the motor rotates to the direction pointed by an arrow label (clockwise seen from a motor fan). If the motor rotates in reverse, interchange two of three phase wires at random.

3. Operation

■ Starting process

Operate the pump by the following procedure.

	Operation procedure	Remarks
1	<ul style="list-style-type: none"> • Open valves. 	<ul style="list-style-type: none"> • Open suction valves fully. • Open discharge valves fully.
2	<ul style="list-style-type: none"> • Prime the pump. 	<ul style="list-style-type: none"> • Prime the pump unit and then close a discharge valve.
3	<ul style="list-style-type: none"> • Check the motor for correct rotating direction. Turn on power and then immediately (within one second) switch off the power. 	<ul style="list-style-type: none"> • Supply power to run the pump only for checking a rotational direction. (The correct direction is indicated with an arrow on the motor.) • Check if the motor fan smoothly stops after the power is turned off. <p>⚠ CAUTION If the motor fan does not stop smoothly, internal parts may contact each other. Check the inside of the pump.</p>
4	<ul style="list-style-type: none"> • Turn on power and start the pump to adjust discharge pressure and capacity. Observer the minimum discharge capacity. See below. 	<ul style="list-style-type: none"> • Run the pump with a discharge valve closed. Once a pressure gauge points the max discharge pressure, open the discharge valve gradually to obtain a specified discharge pressure (or discharge capacity). <p>NOTE: Start to open/close a discharge valve gradually to adjust discharge pressure within one minute after the pump starts to run. Always check a discharge pressure gauge (or adjust discharge capacity by checking a flow meter).</p> <p>⚠ CAUTION Opening a valve sharply, the motor may be overloaded. Always open a valve while checking ammeters.</p>

Operation

	Operation procedure	Remarks
4	<p>Do not operate the pump below the minimum discharge capacity.</p> <p>▶The minimum discharge capacity: 10 L/min MX-250/-251/-400/-401 20 L/min MX-402(H)/-403(H) 50 L/min MX-505</p> <p>• Observe the minimum discharge capacity for the prevention of continuous closed-discharge operation. This rule holds true to not only manual operation but also automatic operation.</p> <p>⚠ CAUTION</p> <p>Do not run the pump longer than one minute with a discharge valve fully closed.</p>	
5	<p><Points to be checked></p> <p>Check a flow meter and confirm that pump operation is as per specifications during operation.</p>	<p>• If a flow meter is not available, calculate a flow rate from discharge pressure, suction pressure and current value, taking account of pipe resistance.</p>

⚠ CAUTION

In case of trouble, turn off power immediately and solve problems. See “**1. Troubleshooting**”.

■ Stopping process

	Operation Procedure	Remarks
1	<p>• Close a discharge valve gradually.</p>	<p>• Do not close a discharge valve sharply whether manually or automatically. Otherwise, the pump may be damaged by water hammer action which tends to occur with a long a discharge line. When using a solenoid valve, set it to close slowly.</p>
2	<p>• Turn off power and stop pump operation.</p>	<p>• Check that the motor stops slowly and smoothly. If it does not stop smoothly, inspect the inside of the pump.</p>
3	<p><Leaving the pump stop></p> <p>• Liquid in the pump may freeze and consequently damage the pump in winter. Drain liquid before storage. When draining harmful liquid, be sure to flush the inside of the pump and piping afterwards.</p> <p>• Use a heater to prevent liquid from freezing when the pump is temporarily stopped in an extremely cold region.</p> <p>• In the event of a power failure, turn off power and close a discharge valve.</p>	

Maintenance

<i>1. Troubleshooting</i>	<i>30</i>
<i>2. Maintenance & Inspection.....</i>	<i>31</i>
<i>3. Spare & Wear parts</i>	<i>34</i>
<i>4. Disassembly & Assembly.....</i>	<i>35</i>

Maintenance

1. Troubleshooting

If you can not find out the root cause of failure, contact us.

Troubles	Symptom		Cause	Point to be checked & Countermeasures
	When a discharge valve is closed.	When a discharge valve is opened.		
Liquid can not be discharged.		The readings of pressure/vacuum gauges drop to zero.	<ul style="list-style-type: none"> Priming liquid level is too low. Dry running 	<ul style="list-style-type: none"> Stop and prime the pump and resume operation.
	The pump can not be primed.		<ul style="list-style-type: none"> A foot valve doesn't close due to foreign matter clogging. 	<ul style="list-style-type: none"> Clean the foot valve and a seat.
	After starting, pressure drops sharply as a discharge valve is opened.	The readings of pressure/vacuum gauges fluctuate and drop to zero.	<ul style="list-style-type: none"> Air ingress through a suction line or a sealing surface. 	<ul style="list-style-type: none"> Check if suction line connections are completely sealed. Check if liquid level in supply tank is not too low.
			<ul style="list-style-type: none"> A disconnection of the magnet coupling 	<ul style="list-style-type: none"> Check amperage to see if the motor is not overloaded. Check if foreign matter does not lock the impeller or magnet capsule. Check if voltage is normal.
Discharge pressure does not rise.		<ul style="list-style-type: none"> Low pump speed The pump rotates in reverse. 	<ul style="list-style-type: none"> Check wiring or motor. Correct wiring. 	
Discharge capacity is too low.	Pressure & vacuum are normal.	Vacuum is high.	<ul style="list-style-type: none"> The strainer is clogged with foreign matter. 	<ul style="list-style-type: none"> Remove foreign matter.
		Vacuum is very high.	<ul style="list-style-type: none"> Air pocket in suction line 	<ul style="list-style-type: none"> Check and correct suction line.
			<ul style="list-style-type: none"> Foreign matter is clogged at impeller inlet. 	<ul style="list-style-type: none"> Remove foreign matter.
		The readings of pressure gauge & vacuum gauge fluctuate.	<ul style="list-style-type: none"> Air ingress from a suction line or a sealing surface. 	<ul style="list-style-type: none"> Check suction line connections and retighten as necessary.
			<ul style="list-style-type: none"> Discharge line clogs with foreign matter. 	<ul style="list-style-type: none"> Remove foreign matter or scale from pump/piping.
		Vacuum is high but pressure is normal.	<ul style="list-style-type: none"> Resistance such as air pocket in suction line. 	<ul style="list-style-type: none"> Check if there is no arched pipework.
	Vacuum is normal but pressure is high.	<ul style="list-style-type: none"> Actual head is too high or pipe resistance is too large. 	<ul style="list-style-type: none"> Check actual head and pipe resistance. 	
Pressure is low and vacuum is very low.	Pressure and vacuum are low.	<ul style="list-style-type: none"> Motor rotates in reverse. 	<ul style="list-style-type: none"> Interchange motor wiring. 	
Motor is overheated.		<ul style="list-style-type: none"> Power voltage is low. Overload 	<ul style="list-style-type: none"> Check voltage or frequency. Check specific gravity and viscosity of liquid. Keep good ventilation. 	
Discharge capacity is rapidly reduced.		Vacuum is high.	<ul style="list-style-type: none"> A suction line clogs with foreign matter. 	<ul style="list-style-type: none"> Remove foreign matter.
Pump vibrates.			<ul style="list-style-type: none"> Poor foundation Loose mounting bolts. Cavitation occurs. Pump bearing is worn or melted. Magnet capsule or spindle is broken. Dynamic balance of drive magnet is upset. The rotating part hits against other parts. Motor bearing is worn. 	<ul style="list-style-type: none"> Reinstall the pump. Retighten the bolts. Remove the cause of cavitation. Replace as necessary. Replace as necessary. Remove the cause. Replace as necessary. Replace as necessary. Replace bearing or motor.

Maintenance

2. Maintenance & Inspection

WARNING

● **Access limitation**

The magnet drive pump has a pair of strong magnets. The strong magnet field could adversely affect the persons who are assisted by electronic devices such as the pacemaker.



● **Turn off power before service**

Risk of electrical shock. Be sure to turn off power to stop the pump and related devices before service is performed.



● **Wear protective clothing**

Always wear protective clothing such as an eye protection, chemical resistant gloves, a mask and a face shield during disassembly, assembly or maintenance work. The specific solution will dictate the degree of protection. Refer to SDS precautions from the solution supplier.



CAUTION

● **Do not catch the finger**

Magnetic force of the pump is powerful. Take care not to catch the finger in the bracket.



■ **Daily inspection**

1. Always check for leakage before pump operation. Do not run the pump when liquid leaks.
2. Check whether the pump runs without abnormal noise or vibration.
3. Check a liquid level in a supply tank and a suction pressure.
4. Check that discharge capacity and a motor current value are as per specifications on the nameplate during operation.

NOTE A discharge pressure is in proportion to the specific gravity of liquid. The cock of a pressure gauge or a vacuum gauge should be opened only when measurement is carried out. Close it right after measurement. If the cock remains open during pump operation, its meter mechanism may be adversely affected by the abnormal pressure rise caused by water hammer action.

5. If a spare pump is stored, run it from time to time to keep it ready for operation at any time when needed.
6. Check discharge pressure, discharge capacity, and motor power supply voltage to see if they do not fluctuate during pump operation. See page 30 "1. Troubleshooting" as necessary.

Maintenance

■ Periodic inspection

To ensure efficient and smooth operation, perform periodic inspection. Be careful not to damage internal sliding parts and plastic parts when dismantling the pump.

The magnetic force of a drive and a driven magnet is strong. Be careful not to catch the finger. Do not put electrical devices such as a watch and a mag card close to those magnets.

Interval	Part names	Inspection items	Measures
Every six months (Maintain an inspection record)	(Drive magnet unit) Drive magnet Hex. socket set screw	<ul style="list-style-type: none"> ● Wear trace ● If the drive magnet is correctly mounted by hex. socket set screws and they are not loose. ● Decentering of magnet and motor shaft (Max.1/10mm) 	<ul style="list-style-type: none"> ○ Finding wear trace, contact us. ○ Reset the drive magnet to the motor shaft and retighten the screws. ○ Retighten the hex. socket set screws or replace the drive magnet (Contact us).
	Rear casing Rear thrust	<ul style="list-style-type: none"> ● Wear tracks on an inner surface ● Cracks ● Wear of the rear thrust ● Contamination in rear casing 	<ul style="list-style-type: none"> ○ Contact us. ○ Replace as necessary. ○ Contact us. ○ Remove contamination.
	(Magnet capsule unit) Magnet capsule Bearing	<ul style="list-style-type: none"> ● Wear tracks on the rear end or side face of the magnet capsule ● Cracks on the rear end or side face of the magnet capsule ● Wear of the bearing ● Loose fit of the impeller unit 	<ul style="list-style-type: none"> ○ Contact us. ○ Contact us. ○ Replace as necessary. ○ Replace or contact us.
	(Impeller unit) Impeller Mouth ring	<ul style="list-style-type: none"> ● Wear of the mouth ring ● Cracks ● Contamination in the impeller ● Impeller deformation 	<ul style="list-style-type: none"> ○ Replace as necessary. ○ Replace as necessary. ○ Remove contamination. ○ Replace as necessary.
	Front case Rear case Liner ring	<ul style="list-style-type: none"> ● Contamination ● Cracks ● Wear, cracks and wear tracks on a liner ring ● Swelling or a crack on O ring ● Wear tracks on an unlikely portion 	<ul style="list-style-type: none"> ○ Remove contamination. ○ Replace as necessary. ○ Contact us. ○ Replace as necessary. ○ Contact us.
	Spindle	<ul style="list-style-type: none"> ● Cracks ● Wear degree 	<ul style="list-style-type: none"> ○ Replace as necessary. ○ Replace as necessary.

Maintenance

■ Wear limits of bearing and spindle

Check wear degree of the bearing and spindle.

Model	MX-250/-251/-400/-401		MX-402/-402(H)/-403/-403(H)/-505	
	Before use	Wear limit	Before use	Wear limit
Bearing inner diameter	18	19	24	25
Spindle outer diameter	18	17	24	23

*If the clearance between the bearing (#21) and the spindle (#20) exceeds 1 mm, either of them, whichever has greater wear, should be replaced regardless of the wear limit. For the pumps with the SiC spindle and SiC bearing (MX-250/-251/-400/-401), replace the both parts at the same time (the whole magnet capsule unit of #8 needs changed to the new one to replace the bearing).


*Sliding parts may suffer initial wear in an initial operation phase but this is not abnormal.

■ Wear limit of mouth ring

Check wear degree of the mouth ring.

Model	Mouth ring thickness	
	Initial thickness	Wear limit
MX-250/-251/-400/-401/-402(H)/-403(H)	8mm	6mm
MX-505	9mm	7mm

*The mouth ring (#22) is 2 mm (3mm for MX-250) forward from the impeller (#3) when shipped. Before the step has reduced to 0 mm, replace the impeller unit.



Maintenance

3. Spare & Wear parts

Appropriate spare parts are necessary for a long period of continuous operation. We recommend that wear parts be always in stock. Place an order for spares with the following information.

1. Part names and part number (See the diagram below.)
2. Pump model identification code and manufacturing number (See pump nameplate.)
3. Drawing number if you have our approval drawing


■ Spare parts list

No.	Part name	MX-250	MX-251	MX-400	MX-401	MX-402	MX-403	MX-402H	MX-403H	MX-505	
1	Front casing unit	MX0109		MX0125	MX0131	MX0799		MX0804		MX0983	
2	Rear casing	MX0110		MX0126	MX0132	MX0802		MX0807		MX0967	
29	Impeller unit 50Hz	IE1	MX0111	-	MX0127	-	MX0176	MX0184	MX0190	MX0191	MX0969
		IE2	MX0991	MX0935	MX0993	MX0937	MX0176	MX0184	MX0190	MX0191	MX0969
		IE3	-	MX0120	-	MX1016	MX0176	MX0184	MX0190	MX0191	MX0969
29	Impeller unit 60Hz	IE1	MX0112	-	MX0128	-	MX0177	MX0185	MX0185	MX0176	MX0968
		IE2	-	MX0121	-	MX1017	MX0177	MX0185	MX0185	MX0176	MX0968
		IE3	-	MX0121	-	MX1017	MX0177	MX0185	MX0185	MX0176	MX0968
8	Magnet capsule unit C (carbon)	MX0113	MX0122	MX0113	MX0122	MX0178	MX0186	MX0178	MX0186		
8	Magnet capsule unit R (PTFE)	MX0114	MX0123	MX0114	MX0123	MX0179	MX0187	MX0179	MX0187		
8	Magnet capsule unit A (Alumina ceramic)	MX0115	MX0124	MX0115	MX0124	-	-	-	-	-	
23	O ring (for casing)	V	MX0116		MX0129	MX0116	MX0180		MX0974		
		E	MX0207		MX0235	MX0207	MX0302		MX0973		
24	O ring (for flange)	V	MX0117		MX0130		MX0181		MX0978		
		E	MX0205		MX0233		MX0300		MX0977		
25	O ring (for flange)	V	-		-		MX0130		MX0976		
		E	-		-		MX0233		MX0975		
20	Spindle	MX0118				MX0182					
19	Rear thrust	MX0119				MX0183					
13	Flange	MX0204		MX0232		MX0298		(13.1) MX0980		(13.2) MX0979	
14		-		-		MX0299		(14.1) MX0982		(14.2) MX0981	
27	Lock pin	-				MX0308					

Note1: The O ring part numbers above are for FKM and EPDM. Contact us for the Aflas® O ring.

Note2: The maximum duration of the above parts (except #23, #24 and #25 O rings) is about 20,000 hours, however, it is based on the operation with clean water at ambient temperature and can change with liquid properties and temperature. For the #23, #24 and #25 O rings, they should be replaced every time the pump head is opened.

Note3: The #20 spindle, #21 bearing and #22 mouth ring must be replaced when the wear limit has come. Note the whole magnet capsule unit (#8) needs to be changed to the new for the replacement of the bearing, and the whole impeller unit (#29) for the replacement of the mouth ring.



MX-250/-251/-400/-401

MX-402/-403/-402H/-403H

MX-505

Maintenance

4. Disassembly & Assembly

WARNING

- **Access limitation**

The magnet drive pump has a pair of strong magnets. The strong magnet field could adversely affect the persons who are assisted by electronic devices such as the pacemaker.



- **Turn off power before service**

Risk of electrical shock. Be sure to turn off power to stop the pump and related devices before service is performed.



- **Wear protective clothing**

Always wear protective clothing such as an eye protection, chemical resistant gloves, a mask and a face shield during disassembly, assembly or maintenance work. The specific solution will dictate the degree of protection. Refer to SDS precautions from the solution supplier.



CAUTION

- **Do not catch the finger**

Magnetic force of the pump is powerful. Take care not to catch the finger in the bracket.



- ▶ Mark each wire so that the wires can be connected correctly to the motor.
- ▶ Do not disassemble the pump beyond the extent shown on this manual.
- ▶ Make sure to close suction and discharge valves before dismantling/assembling the pump. Clean the inside of the pump as well.
- ▶ Magnetic force of the pump is strong. Be careful not to catch the finger in parts. Do not allow iron pieces or powders to stick to a drive and a driven magnet.
- ▶ A pair of strong magnets is mounted in the pump and its magnetic force may affect magnetic disks/ cards or wrist watches. Do not bring them close to the pump.
- ▶ Risk of burning. Pump and pipe surface temperature rise high along with liquid temperature. Do not touch the pump or pipe surface directly in or right after operation.


Maintenance

■ Disassembly (pump head)


1. Remove hex. socket head bolts from the front casing and remove it from the motor bracket.
At this time drain and collect residual liquid and decontaminate wet ends.

⚠ CAUTION

Make sure the pressure is removed from piping or the pump before disconnecting plumbing or disassembly of the pump.



2. Pull out the combination of an impeller unit and a magnet capsule unit. Be careful not to catch the finger in the impeller unit and the bracket.



3. Detach the impeller unit from the magnet capsule unit as necessary. Be careful not to damage the units.

a. MX-250/-251/-400/-401


Slightly tap the back of the impeller unit by a plastic hammer while holding the magnet capsule unit. If it is hard to remove, warm them in hot water (about 90°C) for five minutes.

Be careful not to get scalded with hot water.


Maintenance

b. MX-402(H)/-403(H)/-505

Turn two lock pins 90 degrees anticlockwise using a flathead screwdriver and then push them off inwards. Tap the end of driver handle if necessary.




The lock pins can also be turned by using a 4mm hex. wrench from the inner surface of the magnet capsule unit. In this case turn the wrench clockwise. Note the pins will be damaged if they are turned in a reverse direction. After unlocking, push it off from the outside by using a bar.




After the lock pins are removed, detach the impeller unit from the magnet capsule unit by slightly tapping the back of the impeller unit with a plastic hammer. If the impeller unit is hardly removed, warm it in hot water (approx. 90°C) for five minutes and tap the back slightly. Be careful not to scald in hot water.

The impeller unit can not be separated from the magnet capsule unit unless the lock pins are removed. Do not use excessive force to remove the impeller unit.



- Slide the top of a flathead screw driver in between the rear casing and the motor bracket to pull out the casing. Pay attention not to scratch the O ring surface.




Maintenance

■ Assembly (pump head)

1. Mount the impeller unit to the magnet capsule unit.


a. MX-250/-251/-400/-401

Press the impeller unit into the magnet capsule unit as far as it will go, locating the U-shape holes under the through holes.




Check that the end of press-fitting parts has come at a bearing surface. If the impeller unit can not be press fitted to the magnet capsule unit, warm the magnet capsule unit in hot water (about 90°C for five minutes) for softening. Be careful not to get scalded with hot water.

Check no clearance between the bearing surface and the press-fitting parts.



b. MX-402(H)/-403(H)/-505

The mating surface on the magnet capsule unit has two hole sizes. Large holes (stepped holes of I.D. 6mm and 12mm) are for the lock pins and the small holes (I.D. 3mm) are for cooling. Press the impeller unit into the magnet capsule as far as it will go, locating the U-shape holes under the smaller holes. If it is hard to combine them, warm the magnet capsule unit in hot water (approx. 90°C) for 5 minutes. Be careful not to scald at this time.







Maintenance

After fitting the impeller unit, insert two lock pins all the way seated in the lock pin holes from an inner surface.

Use a flathead screwdriver to turn the pins 90 degrees clockwise from the outside while holding the pins from the inside. Once it clicks, the impeller unit is secured.

If the screw groove is deformed and can not be used, the pins can be turned from the inner surface with a 4mm hex. wrench. In this case turn the wrench anticlockwise. Note these plastic pins may be broken if it is turned in reverse.

2. Insert the combination of the impeller unit and the magnet capsule unit into the rear casing slowly.
Do not allow foreign matter such as iron pieces to adhere to the magnet capsule unit.
3. Mount the rear casing with the combined units in it to the bracket.



CAUTION

Magnet force is very powerful. Place plastic or wooden spacers between the rear casing and the motor bracket so as not to catch the fingers.


Pay extra attention to for MX-402/-403 in this point.

Maintenance

4. Fit an O ring to the front casing. Check that sealing surfaces are free of dust or scratches. Make sure that an O ring is in place and will not be out of a groove.

Mount the front casing to the rear casing according to a pair of mating parts (except the MX-400/-505).

Note that the MX-402 and -403 have two pairs of mating parts.



5. Fasten the front casing to the motor bracket.

Tighten the hex. socket bolts evenly. Tightening torque is shown below.


Model	Tightening torque
MX-250/-251/-400/-401	11.8N•m
MX-402/-402(H)/-403/-403(H)/-505	14.7N•m

Maintenance

■ Disassembly (loose flange)

<MX-505>

1. Turn the combination of the outer and inner flange counter clockwise to detach it from the pump inlet/outlet. Use a belt wrench if necessary.




■ Assembly (loose flange)

<MX-505>

1. Fit an O ring into the groove of the inner flange.
2. Combine the inner flange and the outer flange, using the mating parts as a guide.
3. Turn the combination of the flanges clockwise until it will not turn further.

NOTE: O ring may come out of the groove. Keep it in place while tightening the flanges.





<https://www.iwakipumps.jp>
IWAKI CO.,LTD. 6-6 Kanda-Sudacho 2-chome Chiyoda-ku Tokyo 101-8558 Japan
TEL: +81 3 3254 2935 FAX: +81 3 3252 8892

European Headquarter / IWAKI Europe GmbH
TEL: +49 2154 9254 0 FAX: +49 2154 9254 48

Germany / IWAKI Europe GmbH
TEL: +49 2154 9254 50 FAX: +49 2154 9254 55

The Netherlands / IWAKI Europe GmbH (Netherlands Branch)
TEL: +31 74 2420011 FAX: +49 2154 9254 48

Italy / IWAKI Europe GmbH (Italy Branch)
TEL: +39 0445 561219 FAX: +39 0445 569088

Spain / IWAKI Europe GmbH (Spain Branch)
TEL/FAX: +34 934 741 638

Poland / IWAKI Europe GmbH (East Europe Branch)
TEL: +48 12 347 0755 FAX: +48 12 347 0900

Denmark / IWAKI Nordic A/S
TEL: +45 48 242345

Finland / IWAKI Suomi Oy
TEL: +358 10 201 0490

Norway / IWAKI Norge AS
TEL: +47 23 38 49 00

Sweden / IWAKI Sverige AB
TEL: +46 8 511 72900

Belgium / IWAKI Belgium N.V.
TEL: +32 13 670200 FAX: +32 13 672030

France / IWAKI France S.A.
TEL: +33 1 69 63 33 70 FAX: +33 1 64 49 92 73

U.S.A. / IWAKI America Inc.
TEL: +1 508 429 1440 FAX: +1 508 429 1386

Brazil / IWAKI Do Brasil Comercio De Bombas Hidraulicas LTDA.
TEL/FAX: +55 19 3244 5900

China (Shanghai) / IWAKI Pumps (Shanghai) Co., Ltd.
TEL: +86 21 6272 7502 FAX: +86 21 6272 6929

China (Hong Kong) / IWAKI Pumps Co., Ltd.
TEL: +852 2607 1168 FAX: +852 2607 1000

China (Guangzhou) / GFTZ IWAKI Engineering & Trading Co., Ltd.
TEL: +86 20 84350603 FAX: +86 20 84359181

China (Shenzhen) / IWAKI Pumps (Shenzhen) Co., Ltd.
TEL: +86 0755 8656 3696

Singapore / IWAKI Singapore Pte Ltd.
TEL: +65 6316 2028 FAX: +65 6316 3221

Indonesia / IWAKI Singapore Pte Ltd. (Indonesia Office)
TEL: +62 21 6906606 FAX: +62 21 6906612

Malaysia / IWAKIm SDN. BHD.
TEL: +60 3 7803 8807 FAX: +60 3 7803 4800

Korea / IWAKI Korea Co., Ltd.
TEL: +82 2 6238 4800 FAX: +82 2 6238 4801

Taiwan / IWAKI Pumps Taiwan Co., Ltd.
TEL: +886 2 8227 6900 FAX: +886 2 8227 6818

Thailand / IWAKI (Thailand) Co., Ltd.
TEL: +66 2 322 2471 FAX: +66 2 322 2477

Australia / IWAKI Pumps Australia Pty Ltd.
TEL: +61 2 9899 2411 FAX: +61 2 9899 2421